INSTALLATION INSTRUCTIONS FOR GIMBAL ON CLASSIC FOLDING DECK CHAIR

- 1. Remove the seat bottom (Item #1) by unscrewing the (4) screws (Item #2) securing it to the seat frame.
- 2. Locate the gimbal assembly included with your chair and remove the (4) screws that attach the gimbal cup assembly (Item #3) to the gimbal plate (Item #4).
- 3. Place the gimbal cup assembly onto the bottom of the seat frame in the desired location as shown.
- 4. Install the (4) longer screws (Item #5) through the gimbal plate and into the gimbal cup assembly as shown. The longer screws are provided with your gimbal.
- 5. Tighten the (4) screws so that the gimbal is snug but can still be rotated around the frame rail.



